

# 83.1 Removal and Installation of Ornamental Grille on Air Inlet

107

## Removal

- 1 Remove lower trimstrip on windshield (68.1-540).
- 2 Open engine hood and remove plastic expanding clamps. (Fig. 1).




Fig. 1

- 3 Only on vehicles up to:

Model	Chassis End No.
107.043	003 238
107.044	000 918

Remove both screws (1).

- 4 Remove ornamental grille (2) and screen (3).




Fig. 2

- 1 Screws on ornamental grille
- 2 Ornamental grille
- 3 Screen