

Model 107 123  
except maintenance-free side mirrors

### Grease type


Lubricating grease

Multipurpose grease

**Note:** Maintenance free mirrors can be recognized by the revised mount.

Standard on model 107 and 123, starting January 1984.

Disengage mirror from rear in forward direction by means of a light blow with the ball of the hand.



Lubricate bearings of both locking pins (arrows b) and move mirror back and forth several times.

Grease holding bracket and locking pin (arrows a) at both bearing points.

