

68.1 Removal and Installation of Hat Rack and Tray for First Aid Kit

107

Hat Rack

- 1 Remove rear seat and rear backrest (91.1–170).
- 2 Remove partition between fuel tank and trunk compartment.
- 3 Remove the 3 nuts on hat rack from trunk compartment end.
- 4 Lift out hat rack.
- 5 For installation proceed vice versa.

Tray for First Aid Kit

- 1 Push tray out of rear wall sheet metal with a plastic wedge.

The hat rack is **not** removed for this purpose.